



PIPE & INDUSTRIAL TOOLS

Operator's & Safety Manual

MEGA JACK - 3 LEG



PN 3600

Mega Jack - 3 Leg - PN 3600



Specifications

Model Number: 3600

Weight Capacity: 5,000 lbs.

Adjustable Height: 26" - 40"

Footprint: 30" x 30"

Pipe Capacity: 2-32"

Unit weight: 40 lbs.



PIPE & INDUSTRIAL TOOLS

General Safety Instructions

1. Do not misuse unit. Never attempt to operate the equipment at more than the recommended capacity. Perform only the functions for which the Mega Jack is designed.
2. Keep alert. Never horseplay around equipment and keep bystanders at a safe distance. Do not allow children to be in the work areas or operate the Mega Jack.
3. Keep work area clean. For unobstructed movement around the mega jack, always keep floor in work area clear of clutter.
4. Examine the equipment. Prior to using B&B products, inspect all parts to ensure that they are in proper operating condition.
5. Wear proper personal protection equipment. Welding helmet or hard hat, welding gloves and safety shoes should be worn as a precaution while operating this Mega Jack.
6. Operate only on hard level surfaces. Use the Mega Jack only on smooth and level surfaces to avoid tipping and the possibility of operator injury.

Instructions for Use

Read and understand the instructions for safe performance. Always read operators manual prior to working with the mega jack. Understand the correct operations, applications, and limitations. Store this safety manual in a clear area and always at a readily accessible site. Be especially aware of specific hazards. Extra copies are available from B&B Pipe and Industrial Tools.

1. Check Mega Jack capacity rating and make sure it is not overloaded.
2. Check for damage before using. If damaged, remove from service and do not use.
3. Use on hard level surfaces. Be sure Mega Jack is securely on the ground.
4. Only use the Mega Jack for its intended purposes.
5. Place pipe onto Mega Jack slowly. Do not drop the pipe onto the Mega Jack.
6. Never allow anyone under the pipe while it is supported by the Mega Jack.
7. Do not remove components or alter the Mega Jack in any way.